



MUVEACOUSTICS™
SOUND THAT INSPIRES

USER MANUAL AND WARRANTY



A+Plus Speaker

Bluetooth Connection

Devices with Bluetooth 2.0 wireless technology or above, such as Bluetooth wireless technology equipped computers, smartphones and MP3 players.

To use Bluetooth for your audio connection first pair A+ with your audio source (music player, smartphone, laptop, or other Bluetooth equipped device that can act as audio source). First press and hold the Power button for three seconds or until you hear the tone to turn the power on. Once the power turns on the A+ is in pairing mode. The blue Sync LED will blink slowly and then flash quickly. Make sure Bluetooth is enabled on your audio source and in a few moments "Muve Acoustics: A+" will appear on your list of possible Bluetooth connections. Press "pair" or "connect" on your device and when the connection is made, the blue led will stop to blink and you can hear 1 sec. flat tone. You are paired.

From now on, when you turn on A+ , it will automatically search for the last Bluetooth device it was paired with.

Wired Connection

A+ has a standard 3.5mm audio in jack. If there is no Bluetooth source available or if you simply prefer a wired connection, you can connect your A+ directly to your audio source using a stereo male 3.5mm connection on both ends of the cable.

(This cable is included in the packaging box)

Caution

Changes or modifications not expressly approved by the party responsible for the compliance could void the user's (or your) authority to operate the equipment. Avoid storage in extreme heat or cold. Avoid extreme temperatures and high humidity. The product's working temperature range is -35°C to 60°C (-31°F to 140°F).

WARRANTY CARD

MUVEACOUSTICS™ ONE-YEAR LIMITED WARRANTY

MUVEACOUSTICS™ A+ speaker have been subjected to a thorough series of tests to ensure the highest level of dependability. It is unlikely that you will experience any problem, but if a defect should become apparent during the use of this product, MUVEACOUSTICS™ warrants to the original purchaser that this product will be free from defects in material and workmanship for a period of 12 months from the date of your original purchase from an authorized dealer. If a defect covered by this warranty occurs, MUVEACOUSTICS™, at its option, will repair or replace the product purchase at no repair charge (postage charges will apply).

If a replacement is necessary and your product is no longer available, a comparable product may be substituted at the sole discretion of MUVEACOUSTICS™.

This warranty does not cover normal wear and tear, abusive use or misuse, modification, tampering or by any other cause not related to either materials or workmanship. This warranty does not apply to product used for any industrial, professional or commercial purposes.

For service on any defective under 12 months warranty policy, please contact Consumer Support.

Email: consumersupport@zeeva.com

Telephone Number: 022-67368877

Keep all relevant information for future reference

Designed by:



www.muveacoustics.com

Imported and distributed in India
by Zeeva Electronics Private Limited.
All rights reserved.

901-902, Trade World C wing
Kamla Mill Compound
Senapati Bapat Marg, Lower Parel West
Mumbai-400013

Design, logo and wordmark are intellectual properties of Butani Group Limited.



The input voltage to the product is 5V 0.5A.

In order to charge the product in safe manner and reliable conditions, please only adopt certified appropriate charger / adapter for charging the product.

Only charge the product at ambient temperatures between 10 deg °C / 50 deg °F and 40 deg °C / 104 deg °F.



Do not heat above 70 deg °C / 158 deg °F, eg. Do not expose to sunlight or throw into fire.

Switch off the product after use.

Please note that we won't take any responsibility for any wrong operation (eg. Voltage higher than 5V) as this may result in severe injury or loss of property, and we cannot control the operating process during the time the user using this product. In extreme cases, abuse or misuse of Lithium battery pack can lead to explosion, heat generation, fire development or smoke development.



MUVEACOUSTICS™
SOUND THAT INSPIRES



This device has been tested and complies with part 15 of the FCC rules.
FCC ID: 2AIH3-MA2000-2100

USER MANUAL



Please Note:

A+ offers audio feedback when you use the controls. When you hear the tone A+ is performing the function you've initiated. Functions that include audio feedback include:

- Power On/ Power Off
- Bluetooth pairing available
- Bluetooth pairing completed
- Incoming phone call

1 Power

Press and hold for about 3 seconds to turn the power On/ Off.

Play/Pause

You can play and pause your music using the Power button. To perform this function press and release the button quickly.

Speakerphone

When incoming call ring on your phone you will hear a tone ringing on your A+ speaker. Press and release the Power button to answer/ end a call while A+ is paired with your phone via Bluetooth. Use A+ integrated microphone to speak.

2 Bluetooth Sync Indicator

Blinks blue when ready to pair.

Bluetooth LED will be solid blue when the device is paired.

3 Volume Up

Press and hold to increase volume.

4 Volume Down

Press and hold to decrease volume.

5 USB Port

Micro USB port for charging A+.
(Cable Included)

6 3.5mm Audio Line In

Standard audio in for use without Bluetooth.
(Cable Included)

Battery Level

When the battery voltage is low, white LED light with sound beep. When the battery voltage is very low, device will shut off automatically. White LED light up during charging and it will turn off once fully charged.

Please Note:

A+ comes with a lithium-ion polymer battery.

For best results, fully charge A+ before use. It will take 2-2.5 hours to fully charged.

To charge, plug the micro USB cable into A+ and plug the standard USB connector into your power source.

While A+ is power off and charging the power LED will be solid white.

The Bluetooth will be automatically off and audio signal will go through audio port when a 3.5 mm audio cable plugged in. Bluetooth connection will be automatically restored once the audio cable has been pulled out.